



MX6 Quick Start Guide


Operating Notes




To monitor output signal, connect headphones to jack (10) and use control (9) to set listening volume.



Rotate knob (7) to select SYSTEM CONTROL parameter. Parameter A, B and C: not used.






Rotate knobs (1, 2, 3, 4, 5, 6, 8) to increase (CW) or decrease (CCW) selected parameter for each channel.



LOCK: To lock all controls, hold down SYSTEM CONTROL (7) and OUT (8) knobs simultaneously for three seconds.

MUTE: Briefly pressing an input or output knob, exception headphone (9), causes the corresponding channel to be muted. The MUTE function is indicated by the steady flashing of the LED ring. Another brief press of the knob removes the MUTE function.



Specifications subject to change without notice. Technische Änderungen vorbehalten. Ces caractéristiques sont susceptibles de modifications. Ci riserviamo il diritto di effettuare modifiche tecniche. Nos reservamos el derecho de introducir modificaciones técnicas. Especificações sujeitas a mudanças sem aviso prévio.

MX6 Quick Start Guide



Setting Up

